



FET GUITAR PREAMP WITH BYPASS CAP

PCB Layout By Paul Marossy
9/16/05

NOTES:

1. Use J201 FET for best results.
2. Adjust 10K trimpot to 5-7 volts for maximum headroom w/ 9V battery
3. To increase gain even more, change value of 3.3uF cap to 4.7uF or 6.8uF
4. To decrease gain, remove 3.3uF cap.

