



NOTES: ISOLATING SWITCH FROM ENCLOSURE IS NOT NECESSARY.

CABLE IS HARD WIRED TO SWITCH.

## FOOTSWITCH WIRING DIAGRAM SEYMOUR DUNCAN CONVERTIBLE

11/13/02 PAUL MAROSSY