double ® super sound

Made in Italy by JEN Elettronica S.p.A. PESCARA





This unit comes complete with battery already fitted. When a lead plug is inserted in the instrument Jack Socket the battery is switched on and the unit operative. Always remove this plug when the unit is not in use otherwise the battery will run down. Check the battery periodically and replace as necessary. When the battery is running down a "sizzling" effect is noticed. To replace the battery, first take off the bottom plate by removing the four screws holding the rubber feet.

There are four settings on this unit:

- 1. Direct to Amplifier
 - 2. Wah Wah
 - 3. Fuzz
 - 4. Fuzz Wah

These are obtained by using the side switch in conjunction with the switch under the pedal.

Patent Pending

250.424