


WAH WAH PEDAL



HOW TO PLAY!

- (1) Connect instrument to "INPUT".
- (2) Connect amplifier to "OUTPUT".
- (3) Foot switch located under pedal, activates or cancels wah wah effect.
- (4) Obtain wah wah sound by operating foot pedal.

CAUTION

To prolong battery (006P/9V) life, pull out plugs when not in use!

To change battery, take off bottom cover.