## Seymour Duncan ®

## CHANGING MODULES

The five factory installed preamp modules are located directly under the Quick Access™ module system plate on the top of the amp. Changing modules is quick and easy. Dramatic tone changes are possible just by rearranging your present module configuration. To replace or rearrange the modules, just follow these easy steps.

## TO REMOVE:

- 1. UNPLUG YOUR AMPLIFIER from the power outlet.
- 2. Turn the Quick Access plate screws counter-clockwise they will pop up.
- 3. Remove the plate.
- 4. Looking down inside the amplifier, firmly grasp the module you want to replace by its handle and lift slowly. When the module is free from its receptacle, continue to lift upward. You may have to turn the module sideways to clear the module opening.

## TO REPLACE:

- 1. MAKE SURE THE AMPLIFIER IS STILL UNPLUGGED.
- 2. Choose the module you want to install and grasp by its handle.
- 3. Insert the module to be installed through the Quick Access module system opening. It may be necessary to turn the module sideways before it will fit through the module opening.
- 4. Align the module plug to be installed over the receptacle in the module position you have chosen.
- 5. Slowly insert the module into the receptacle. Apply moderate pressure until you feel the module is seated snugly.
- Repeat steps 2 thru 5 for each module you want to replace/ rearrange. When you have finished changing modules, doublecheck all modules to ensure they are still snug in their receptacles.
- 7. Align the module system plate with the holes in the top of the amplifier cabinet and then secure.
- 8. Make sure that the Volume and Variable Power controls are at a low setting and Standby switch is place in the ON position.
- 9. Plug the power cord from the amplifier into the 110-120Vac wall outlet and place the Amp Power switch in the ON position.
- 10. After a one-minute warm-up, flip Standby switch on the rear panel to the "ON" position and you're ready to play.